Solar LED Post Top Light

Installation steps

① Connect the lamp head to the bracket, Fasten both sides of the bracket with two short screws



② Fasten them with two long screws




③ Press the white switch button and cover the solar panel. Hearing a click means it's on, and the light will light up after 10 seconds




④ Put the bracket on the light pole and fasten it with four screws



⑤ Drive the expansion bolts into the proper position



⑥ Then put in the spacer and tighten the nut to complete the installation



Product List



1 Lamp holder



2 Lamp arm

4 Manual



5 Flat head cross screws. short



6 Flat head cross screws. long



★ Precautions

- Please pay attention to fixing lamps so as not to hurt people when the wind blows.
- In order not to affect the use of lights, clean up the dust and dirt on the surface of the solar panels every 3 months.
- Please check regularly whether the thread has come off or broken.
- Solar powered lamps contain batteries. Batteries are recyclables. Please do not litter.

