LED Parking Garage

Installation guide

⚠ Notice

PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION

— To prevent personal injury or product damage only licensed electricians should install.
— To avoid electric shock or component damage disconnect power before attempting installation or servicing.
— This product must be installed in accordance with the national electric code (NEC) and all applicable federal, state and local electric codes and safety standards.
— Disconnect product and allow cooling prior to servicing.
— Any alteration or modification of this product is expressly forbidden as it may cause serious personal injury, death, property damage and/or product malfunction.
— To prevent product malfunction and/or electrical shock this product must be properly grounded.
— This luminaire is designed to operate in ambient temperatures ranging from -30° c to 40° c and to be horizontally mounted with the
LEDs facing down.

1、Unpacking

Check the damage fixture thoroughly, Report to the carrier if goods damaged

1. Installation



1)Loosen the two bolts of the LED Junction-box and release the Junction-Box. (Picture 1)



2)Install the junction box to ceiling pendant position, (Picture 2)



3) The professional electrician uses the correct installation tools to install the Junction-box and install the power line properly(Picture 3)



4) Check that the power line is properly installed and tighten the two bolts of the screw(Picture 4)

2. Installation



1)Loosen the two bolts of the LED Junction-box and release the Junction-Box. (Picture 1)



2)Install junction box to ceiling position(Picture 2)



3) The professional electrician uses the correct installation tools to install the Junction-box and install the power line properly(Picture 3)



4) Check that the power line is properly installed and tighten the two bolts of the screw(Picture 4)

The wiring diagram is as follows

