Installation Guide

⚠ WARNING

PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION


- To prevent personal injury or product damage only licensed electricians should install.
- To avoid electric shock or component damage disconnect power before attempting installation or servicing.
- This product must be installed in accordance with the national electric code (NEC) and all applicable federal, state and local electric codes and safety standards.
- Disconnect product and allow cooling prior to servicing.
- Any alteration or modification of this product is expressly forbidden as it may cause serious personal injury, death, property damage and/or product malfunction.
- To prevent product malfunction and/or electrical shock this product must be properly grounded.
- This luminaire is designed to operate in ambient temperatures ranging from -30° c to 40° c .
- LED Surface Down Lights only.

1. Unpacking


Thoroughly inspect the fixture for freight damage. Freight damage should be reported to the delivery carrier.

2. Installation


1). Click the round backplate out of the lamp body




2). Using the kit screws, punch the screws into the holes as shown. Hang the safety cord.




3) Connect the AC line of the lamp.




4). Hanging the lamp on the mounting plate.



CCT & Wattage Adjustable instructions





3. Checking

1). Does all the wires connect in a correct way as the pictures show below?

2). Is the ground lead installed appropriately?