LED Emergency Light

TYPE: BLD-ACEXX03-0XYOS

LED Emergency Light Unique all-inclusive lamp, reflector, and lens assembly. Ultra-bright, energy efficient, long-life. White LED adjustable and movable heads. This design is great for placing in airport terminals , isles, restaurants, office buildings and warehouses.



BLD-ACEXX03-0XYOS

SPECIFICATION	
TYPE	BLD-ACEXX03-0XYOS
WORKING VOLTAGE	100-347V 50Hz/60Hz
LUMEN	356 Lm
POWER	3W
CCT	5000K
RECHARGE TIME	24 Hours
EMERGENCY DURATION	≥90 Mins
BATTERY	7.3V/2600mA
FACTORY SETTING	Standard / No Bluetooth
ENVIRONMENT	Damp
WORKING TEMPERATURE	5ºC ~ 50ºC
CERTIFICATION	UL
FIRE RATING	5VA
CABLE	Input Connect, No cable
BLUETOOTH CONTROL	Optional
WARRANTY	5 year limited

DIMENSION:



WATTAGE	BLD-ACEXX03-0XYOS
NT. WEIGHT	1.79 lbs(N.W)
BOX DIM.	11.00" x 6.25" x 3.14"(1Pcs/CTN)
OUTER BOX	13.58" x 12.0" x 16.53"(10Pcs/CTN)

LED Emergency Light

TYPE: BLD-ACEXX03-0XYOS

ORDERING INFORMATION

EXAMPLE:

BLD-ACEXX03-0XYOS

BLD	ACEXX03	0XYOS
CODE	WATTAGE	FINISH
	03 (3 W)	White

ACCESSORIES (Standard)



Standard Installation Kit

ACCESSORIES (SOLD SEPARATELY)



BLD-ACEXX03-0XYOS-ZJ
Emergency Light Mounting Bracket Kit

INDICATOR LIGHT INTRODUCTION

① Red/ON: Charging ② Green/ON: Full-charged ③ Indicator light OFF: Discharging(emergency mode)
④ Green/Flashing: Self-testing ⑤ Red Flashing:Error

Note: See Trouble Shooting Guide



Mode	LED Indicators Status	Error	EM Driver Status / Mode	Corrective Action
Normal	Solid Green	None	Battery fully charged/System OK	/
	Solid Red	None	Battery is charging	/
	Both LEDs OFF	None	In EM mode or emergency run-time is ended	/
	Flashing Green	None	Self-Diagnostic test underway	/
Fault Mode	Flashing Red	Battery	Battery not connected Battery failure	1.Check battery switch or connection. 2.Replace battery. 3.Contact after-sales.
	Flashing Red	LED Load		1. Check whether there are short circuits, damage, dimming wires connection wrong or loose. 2.Contact after-sales.

MANUAL TEST

Test Mode	Description	Action	Status	Quit
Fast Test	Quick discharge test	Press the test button 1 time	LED load will flash for 5s	/
Monthly	30-second test	Press the test button 3s continuously	LED load will flash for 30s	Hold the test button/switch for 1s
Annually	90-minute test	Press the test button 6s continuously	LED load will flash for 90 minutes	Hold the test button/switch for 1s

LED Emergency Light

TYPE: BLD-ACEXX03-0XYOS

Mounting Instructions

NOTE: First turn off electricity.

1 Remove the screw plug cover and the screws, then separate the lamp body (A) from the rear case (G).



2 Knock off the rear cover (G) knock-off hole.(Spring installation, jump to step 7)



3 Mounting bracket: Not included (additional purchase required)



Measure the spacing of the cross beams. The supports B (D) and A (E) are fixed together through the support mounting plate (F).Position the support travel distance according to the cross beam spacing, and pre-lock two screws to fix one side.（Shaft travel 370mm-630mm)。

4 The bracket is combined with the rear cover (G) and is fixed by locking 4 butterfly nuts.



5 When the two ends of the bracket are pressed against the crossbeam, tighten the other two screws of the fixing plate (F) of the bracket. Hit the hooks at both ends of the bracket B(D) and bracket A(E) to fix them to the crossbeam, and then lock the 8 screws.screws.



6 Connect the lines. Pass the wires through the knocked-out holes on the rear cover (G). Refer to "Step 8" for connecting the lines. -The lamp body (A) is inserted into the rear cover (G), fixed with screws, and then pressed into the screw plug cover. (The bracket installation is completed.)



7 Spring mounting



-Make a hole at the position of the opening card and reserve the power cable.
-Connect the lines. Pass the wires through the wire hole in the rear cover (G).Refer to "Step 8" for connecting the lines.
-The lamp body (A) is inserted into the rear cover (G),fixed with screws, and then pressed into the screw cap.

8 Connecting the wiring

-Use wire clips to connect the wires.
-Use black and white wires. Connect the black power wire to the black fixture wire, and the white power wire to the white fixture wire.



9 Press down on the spring and push the lamp into the hole. (The spring is installed successfully.)



bracket mounting



spring mounting

Part	Description	Quantity
A	Lamp body	1
B	Circular decorative panel	1
C	Square decorative panel	1
D	Bracket B(optional)	2
E	Bracket A(optional)	2
F	support plate(optional)	2
G	rear case	1
H	Spring	2